

2023



User's Manual



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com



Qbus Cloud User's Manual

• Living Room

The glass multi-touch switch found in the living room, located to the left of the main entrance, can be used for a number of functions such as:

- turn perimeter lights on/off
- turning on/off the lights outside the house,
- switch the pool lights on/off,
- turning on/off the lights inside the living room area and in the corridor,
- opening and closing the roller blinds.
- activation/deactivation of the heating/air conditioning in the house.
- activation/deactivation of the electric water heater

To start any function, it is enough to select the corresponding icon in the screen menu.

From the idle screen by touching the bar on the left of the touch screen (Fig.1) it is possible to enter the main screen menu (Fig.2)



Fig. 1 Idle Screen



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com




Fig.2 Main Menu Screen

There are four options available from the main screen menu.

- Touching option No. 1 Activates/deactivates the spot lighting on the ceiling in the living room area.
- Touching option No. 2 activates/deactivates the lighting (spot) in the corridor area.
- Touching option No. 3 activates/deactivates the led lights of the hidden lighting on the ceiling as well as above the TV.
- Touching option No. 4 Activates/deactivates the additional led lighting on the ceiling of the living room.
- If the user wishes to open/close the roller blinds, can touch the bar on the left of the screen (Fig.2) to move to the secondary options menu (Fig.3). In the appropriate menu by pressing the option No 1 can put into operation and activate the left/right roller, and by pressing the option No 2 can choose to close it. Similarly by selecting the right roller blind (from the left scroll bar) can choose to open or close it.



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com





Fig.3 Roller Blind Menu

-In case the user wishes to activate the entrance lights by scrolling the bar on the left of the screen, moves to the “Entry” option (Fig. 4). By pressing the option No 1 can activate the entrance lights while by pressing the option No 2 can turn off the entrance lights which after a period of ten seconds will automatically be switched off.



-To activate the perimeter lighting the user by scrolling the left bar can move to the “Perimeter 1” or “Perimeter 2” menu (Fig. 5) in order to activate the perimeter lighting “one” or “two” by pressing option No 1. In the same way can deactivate the perimeter lights by pressing option No 2 in each case.



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com




Fig. 5 Perimeter Lights

-To activate the external lighting of the house (LED pool lights and lights on the flowers inside) the user by scrolling the left bar on the screen, can move to “Outlights” menu (Fig. 6) in order to activate the lights by pressing option No 1. In the same way to deactivate the lights the user has to press the option No 2.




Fig. 5 Outside Lights



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com

-By scrolling the bar on the screen and moving to the “poollight” menu (Fig. 7) the user can activate the pool lights by pressing the option No 1 and deactivate them by pressing option No 2.




Fig. 7 Pool Lights Menu

-To activate the heating/cooling, the user can move to the “HEAT” or “COOL” menu, by scrolling the left bar, (Fig. 8). By pressing option 1 or 2 each menu is activated/deactivated.




Fig. 8 Cooling / Heating Menu



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com



Fig. 9 Temperature Menu

Accordingly, by scrolling the right bar, you can proceed to select the desired temperature. The operating speed of the fan is determined automatically without user's intervention.

Attention: Inception of the central heating/cooling implies a corresponding start for the other rooms with the right for each user in them, to set the desired temperature. The fan speed in the rooms is automatically configured according to the difference of the selected temperature in in the living room.



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com

- **Bedroom No1-No2**

With the glass multiswitch in each room the user has the following options:

- Activation/deactivation of the ceiling spots
- Activation/deactivation of the led lighting
- Opening/Closing the roller blind
- Room temperature selection for air conditioning/heating
- Activation/deactivation of the external lighting

To activate the ceiling spots, the user starting from the idle screen, (Fig. 10) to press the left scroll bar to go to the main menu screen (Fig. 11)



Fig. 10 Idle screen

From there, by pressing option No1, are activated and deactivated respectively the ceiling spots. (Fig. 11)



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com

Option No 1




Fig. 11 Main Menu Screen

To activate/deactivate the led lighting, the user just needs to press option No2. (Fig. 12)

Option No 2




Fig. 12 Activation/deactivation of the led lights

If the user wishes to activate/deactivate the external lighting, should press option No. 3 (Fig. 13)



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com




Fig. 13 Activation/deactivation of the external lighting

If the user wishes to open or close the roller blinds it is enough to press the left scroll bar and go to the secondary menu. (Fig. 14 and 15)




Fig. 14 Left Scroll Bar



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com




Fig. 15 Secondary Menu

To open the roller blind, the user can press Option «1», or Option «2» to close it (Fig. 16)




Fig. 16 Activation/Deactivation of roller blind



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com

To select the temperature in each room, the user has to press the left scroll bar again and go to the Temperature menu (Fig. 17)



Fig 17 Temperature Menu

By pressing the scroll bar on the right the user can select the desired temperature. (Fig. 17)

By pressing option 1 or 2 respectively, the user can choose one of the preset states (Noclock-Freeze-Economy-Comfort-Night).



Paidochori Apokorwnou
Chania city, P.C.73008



+30 6937041463
+30 6931579440



kallosvilla@gmail.com